

How to install 8303/8313 and 8316/8317 Walls



Use a metal cutting band saw or hack saw, to separate each layer of stone or cribbing. Wear a dust mask and make sure you clean up afterward because the dust is flammable, like sawdust. Try to ventilate the room, due to the pungent plastic resin odors.



The embankment you select can be one level or a stepped wall into a hill like the above photos. Use hotglue to attach and hold in place.



You can stagger and place walls end to end as needed.



We recommend Red Devil One Time patching putty. It's light and easy to use and best of all, water soluble!



You can use a damp brush to even out the Red Devil patching putty.



After the putty hardens overnight, you can "wash" the castings with a diluted gray acrylic paint. Allow to dry and apply earth colors and scenery "dirt" to your liking.



Here are a couple examples of a finished walls and cribbing. You can interconnect the walls as far as you want to go! Send us pictures of what you have done and we will try to share them with other modelers!